07 FEB 2005

10/523877

FIG. 1

1. PORTABLE TERMINAL DEVICE
2. CHARACTER RECOGNITION PROCESSING DEVICE
3. IMAGE FETCHING PART
4. CURSOR CONTROL PART
5. LAYOUT ANALYZING PART
6. CHARACTER CUTTING PART
7. CHARACTER RECOGNIZING PART
8. FORMAT OUTPUT PART
9. PHOTOGRAPHING PART
10. DISPLAY CONTROL PART
11. APPLICATION PART
12. DISPLAY

Fig. 1

~~図2~~

Fig. 2


18
12
1
19
AB@CD. EFG. HI
01-2345-6789
JKLMNOPQRST
16
AB@CD
01-23
JKLMN
UVWX
FGHIJK
QRSTU
17

Fig. 3


22
12
19
1
18
23
ABCDE
01234
ABCDE
01234
ABCDE
01234
ABCDEFGHIJKLMNOPQRSTUVW
0123456789012
RSTUVW
789012
RSTUVW
789012
RSTUVW
789012
ABCDEFGHIJKL
01234567890 1
ABCDEFGHIJKL

Fig. 4

図4


FRAME (1)
ABCDEFGHIJKL MNOPQRSTUVW
ABCDEFGHIJKL
FRAME (2)
ABCDEFGHIJKLMNOPQRSTUVW
FGHIJKLMNOP
FRAME (3)
ABCDEFGHIJKLMNOPQRSTUVW
JKLMNOPQRSTU
FRAME (4)
ABCDEFGHIJKLMNOPQRSTUVW
OPQRSTUVW
ABCDEFGHIJKLMNOPQRSTUVW
FINAL CHARACTER RECOGNIZED RESULT
CHARACTER RECOGNIZED RESULT

Fig. 5
図5


(A)
30
33
31
PF2
PF3
PF1
PF4
PF5
ON
OFF
32
36
1
2
3
4
5
6
7
8
9
*
0
#
(B)
30
34
35
31
32

Fig. 6



FIG. 6

41. PHOTOGRAPHING PART

42. OPERATING PART

43. DISPLAY PART

44. COMMUNICATION PART

45. AUDIO PROCESSING PART

46. STORING PART

47. CONTROL PROCESSING PART

Fig. 7



FIG. 7

41. PHOTOGRAPHING PART

51. CHARACTER RECOGNIZING PART

52. CHARACTER USING PART

10/523877

Fig. 8

図8



51. CHARACTER RECOGNIZING PART

61. TEMPORARILY STORING PART

62. STORING PART

63. OUTPUT PART

64. TYPE DECIDING PART

Fig. 9

図9



図10

Fig. 10



FIG. 9

71. MAIN MENU SCREEN

72. PREVIEW DISPLAY SCREEN

73. CAMERA FUNCTION SETTING SCREEN

74. RECOGNIZED MODE SETTING SCREEN

75. RECOGNIZED CHARACTER DISPLAY SCREEN

76. FUNCTION MENU SCREEN

77. FUNCTION SCREEN

78. USING SCREEN

10/523817

Fig.11

図11


71
メインメニュー
MAIN MANU
1 未登録
2 未登録
3 09012345678
4 http://○○○○.com/
5 未登録
6 未登録
7 未登録
8 未登録
NON-REGISTERED
選択
SELECT

Fig.12

図12


(A)
(B)
(C)
72
73
74
81
82
E-mail taro @ ××
http://××××.co.
A
撮影 機能
PHOTOGRAPH
FUNCTION
「機能」
FUNCTION
CAMERA FUNCTION
カメラ機能
1 認識モード
2 明暗調整
3 フォトライト
ADJUSTMENT OF BRIGHTNESS
PHOTO-LIGHT
選択
SELECT
「選択」
SELECT
RECOGNIZED MODE
認識モード
1 自動
2 URL
3 メールアドレス
4 電話番号
5 FREE
AUTOMATIC
MAIL ADRESS
TELEPHONE NUMBER
選択
SELECT



Fig.13

10/523877